



# Flash BIOS by UEFI BIOS Setup Utility (Step-by-Step Guide)


## IMPORTANT!

Only update your bios if system is unstable, or bug fixes provided correspond to your needs. Flashing the bios incorrectly has risk to brick your system. See to it that the guide will be followed step-by-step.


### Things to prepare:

- USB Flash Drive
- Laptop/NB system
- NB default power supply
- Internet connection
- 


1. Visit MSI official website and download the corresponding Win8 bios of your system.



2. Extract the downloaded file to your USB drive.




3. If above steps are finished, please shut down the system directly by press Shift and click shut down icon.




4. Power up your NB by plugging in power adapter. Make sure that NB is running AC power during the entire bios update process.




5. Power on NB and continue pressing “DEL”, until you are prompted to bios screen. See figure below:




6. Use Arrow key to switch to “Advanced” setup, select “UEFI BIOS Update” and press Enter.




## 7. Press Enter to start "UEFI BIOS Update".




## 8. Select the USB device which you saved the BIOS ROM file.




- Select the folder you saved the BIOS ROM. Or if you save ROM file to root folder, please go to next step.




- Find the BIOS rom file and press Enter to continue.



11. Select “Yes” to continue.




12. System would prompt you press OK to restart laptop.






13. After system restart, it would automatically enter flash screen, please press Enter to start "Proceed with flash update".



14. Press OK after following process completed. System will restart and BIOS flash is finished now.



Now, your Windows 8 bios has been successfully updated. Enjoy!