




This guide shows steps to update BIOS along with EC firmware for MSI Claw.

- * Note 1: Keep the AC power connected during the whole update process.
- * Note 2: Save all unfinished works before proceeding the BIOS update.
- * Note 3: Custom setup of any advanced settings such as undervolting/overclocking must be restored to default before starting the BIOS update.



⑥ Wait until the system reboots automatically and complete BIOS update.

***If the system auto restart is stopped or canceled, the update will continue in the next system restart.**